

## CT711 Install Guide


### Installing LANforge to manage the CT711 RF Noise Generator.

The CT711 should only be used for RF noise generation and interference. For RADAR emulation, consider the [CT712](#).

The primary purpose of the CT711 is for constant modulated (OFDM, CCK, HT) noise generation for CCA testing.

### Overview

The CT711 requires LANforge to be installed on an available Linux system (Fedora 24 or higher). The Linux system should also have access to the internet to download LANforge software.



### Automated Install

To install the LANforge server and GUI use the below guide. Step 4 is required for the CT711 to work!

[Automated Linux Install/Upgrade Instructions](#)